

- **ABS Fault Codes Page**

A complete list of fault codes for the Teves Mk II and Mk IV as fitted to the Ford Granada range 1989-1994.

| Code | Unit | | Fault |
|--------------------|----------------|-----------------|------------------------------|
| | Type | Position | |
| 00 | ECU | - | Supply voltage or ECU |
| 10 | - | - | Invalid code |
| 11 | - | - | Electrical interference |
| 17 | System Relay | - | Voltage supply or wiring |
| 21 | Main Valve | - | Valve, wiring or connections |
| 22 | Solenoid valve | LH Front inlet | |
| 23 | | LH Front outlet | |
| 24 | | RH Front inlet | |
| 25 | | RH Front outlet | |
| 26 | | Rear inlet | |
| 27 | | Rear outlet | |
| 31 | | | LH Front |
| 32 | RH Front | | |
| 33 | RH Rear | | |
| 34 | LH Rear | | |
| 35 | Speed sensor | LH Front | Sensor signal |
| 36 | | RH Front | |
| 37 | | RH Rear | |
| 38 | | LH Rear | |
| 41 | | LH Front | |
| 42 | | RH Front | |
| 43 | | RH Rear | |
| 44 | | LH Rear | |
| 55 | | LH Front | Sensor signal long term |
| 56 | | RH Front | |
| 57 | | RH Rear | |

| | | | |
|--------------------|-------------------------------|----------|---|
| 58 | | LH Rear | |
| 61 | Reservoir and pressure switch | | Switches, pump motor, relay or wiring |
| 62 | Pedal travel sensor | | Sensor resistance or wiring (Mk IV only) |
| 63 | Motor | - | Motor, voltage supply, relay or wiring (Mk IV only) |
| 64 | Hydraulic Modulator | | |
| 65 | G force sensor | - | Sensor or wiring (4x4 only) |
| 75 | Speed sensor | LH Front | Sensor circuit intermittent fault |
| 76 | | RH Front | |
| 77 | | RH Rear | |
| 78 | | LH Rear | |
| 79 | Vehicle spin recognised | | - |

[Home](#)